

Grout Pumps



- Competency on pump and its blockage procedure to be checked prior to work.
- Pumps pre start checks to be carried out(refer to manufacturers manual).
- The pump is to be set up in a suitable place in an adequate bund to manage spillages and or any environmental issues.
- Grout mix design to be checked by operator prior to work beginning to ensure compliance.
- Ensure correct PPE and RPE is used and the operator is face fit tested for the correct mask.
- Materials to be stored at a safe and useable height to avoid manual handling issues.
- Operator to check grout lines and ensure whip checks are used prior to pumping
- A clear line of communication is to be established.
- The operator needs to know where the wash out area is in order to wash out at the end of the shift